



PORSCHE 968 ADDENDUM PILOT BEARING INSTALLATION

Specific Model Instructions:

The pilot bearing must be installed using a permanent type of Loctite®. The Loctite® should be applied to the outside of the bearing once the correct bearing depth is found. Allow the Loctite® to set up before installing flywheel. Follow the set up criteria on the bottle.

Legal Policy: HIGH PERFORMANCE PARTS, SERVICE AND INFORMATION EXCLUDED FROM WARRANTY: Due to the unusual stress placed on high performance parts, and because of the circumstances under which they are often used, high performance parts are sold without warranty, AS IS, WITH ALL FAULTS, and all warranties, expressed or implied, of merchantability, or of fitness for a particular purpose, or otherwise are expressly disclaimed and denied.

FP 4285 Main Street Perry Ohio 44081 • PH 1.440.259.5656 • Fax 1.440.259.5588 • www.fidanza.com



PORSCHE 968 ADDENDUM PILOT BEARING INSTALLATION

Specific Model Instructions:

The pilot bearing must be installed using a permanent type of Loctite®. The Loctite® should be applied to the outside of the bearing once the correct bearing depth is found. Allow the Loctite® to set up before installing flywheel. Follow the set up criteria on the bottle.

Legal Policy: HIGH PERFORMANCE PARTS, SERVICE AND INFORMATION EXCLUDED FROM WARRANTY: Due to the unusual stress placed on high performance parts, and because of the circumstances under which they are often used, high performance parts are sold without warranty, AS IS, WITH ALL FAULTS, and all warranties, expressed or implied, of merchantability, or of fitness for a particular purpose, or otherwise are expressly disclaimed and denied.

FP 4285 Main Street Perry Ohio 44081 • PH 1.440.259.5656 • Fax 1.440.259.5588 • www.fidanza.com